

## Angle Iron Installation Instructions

## www.generalmetals.com

- 1. Verfy proper support is below roof line and position AI Stand on the roof.
- 2. Loosen 4 3/4" Bolts with 9/16 Wrench.
- 3. Place level on the stand and adjust the base to level position.
- 4. Tighten 4 #10 3/4" bolts to approx 35 pound torque.
- 5. Attach 4 #10x3/4" self drill screws to each leg support to lock frame in place.
- 6. Saw off excess leg supports prior to settings the unit to reinforce a clean installation. In addition, it will provide service panel access.

Notes: The self tapping screws are vital to keep the stand from slipping. **DO NOT** rely on the ability of the 4 3/8" bolts to do the job.

To keep cost on the AI stand competitive they are not painted. We do supply you one free can of gray primer paint with purchase.

